

Disassemblare completamente il portatarga /parafango posteriore originale, staccare il cavo e togliere la serratura sella dallo stesso.

Applicare alla piastra sotto codone VMC il fanale posteriore in dotazione, il supporto targa (tramite la vite TBEI 6 x 12 e relativo dado flangiato) e la serratura sella come in figura 1.

Collegare i cavi alimentazione fanale posteriore nel seguente ordine:

GIALLO = POSIZIONE
NERO = NEGATIVO
ROSSO = LUCE STOP

Posizionare ed avvitare tramite le 4 viti TBEI 6 x 25 e le viti superiori standard interponendo tra il telaio posteriore e la piastra sotto codone VMC i distanziali da 18 mm. in dotazione.

Posizionare il supporto targa come in FIG: 2

Dismount std. license plate holder and rear mud guard , keep seat lock .

Fix together VMC under seat –plate ,rear light ,and license plate bracket(by 6mm x 12 and relative bolt) like PIC. 1

Connect rear light wiring :

*YELLOW = POSITION LIGHT
BLACK = HEART
RED = BRAKE LIGHT*

*Bolt –on by the four 6 x 25 mm. bolts and std. mud guard upper bolts the VMC under seat plate.
Remember to put between subframe and our under seat plate the four 18 mm. dedicated spacers.*

Fix all together like PIC. 2



FIG.1



FIG.2