

Smontare la sella, la paratia plastica posizionata nella parte inferiore del codone, e il portatarga originale. Posizionare ed avvitare (utilizzando le 4 viti originali) la staffa porta targa VMC (fig 1). Posizionare la vite che andrà a fissare la staffa a "Z" di sostegno della paratia plastica (fig 2).

Posizionare ed avvitare, utilizzando la vite che si è precedentemente posizionata e il dado M6 autobloccante, la staffa a "Z" che chiude la parte inferiore del codone e sostiene la paratia plastica del codone (fig 3 e 4).

Posizionare ed avvitare il supporto porta targa VMC (fig 5).

*Remove the seat, the bulkhead located at the bottom of the plastic tail, and the original holder. Position and screw (using the 4 original screws) the license plate bracket VMC (fig 1). Place the screw that will secure the bracket to "Z" to support the bulkhead plastic (Figure 2).*

*Position and screw using the screw that was previously positioned and self-locking nut M6, bracket to "Z" that closes the bottom of the tail and supports the bulkhead plastic codon (Fig. 3 and 4). Position and secure the VMC license plate support (Fig. 5).*

