

Disassemblare completamente il portatarga /parafango posteriore originale, staccare il cavo e togliere la serratura sella dallo stesso.

Applicare alla piastra sotto codone VMC il fanale posteriore in dotazione, il supporto targa (tramite la vite TBEI 6 x 12 e relativo dado flangiato) e la serratura sella come in figura 1.

Collegare i cavi alimentazione fanale posteriore nel seguente ordine:

GIALLO = POSIZIONE

NERO = NEGATIVO

ROSSO = LUCE STOP

Posizionare ed avvitare tramite le 4 viti TBEI 6 x 25 e le viti superiori standard interponendo tra il telaio posteriore e la piastra sotto codone VMC i distanziali da 18 mm. in dotazione.

Posizionare il supporto targa come in FIG: 2

*Dismount std. license plate holder and rear mud guard, keep seat lock.*

*Fix together VMC under seat -plate, rear light, and license plate bracket (by 6mm x 12 and relative bolt) like PIC. 1*

*Connect rear light wiring :*

*YELLOW = POSITION LIGHT*

*BLACK = HEART*

*RED = BRAKE LIGHT*

*Bolt -on by the four 6 x 25 mm. bolts and std. mud guard upper bolts the VMC under seat plate.*

*Remember to put between subframe and our under seat plate the four 18 mm. dedicated spacers.*

*Fix all together like PIC. 2*



**FIG.1**



**FIG.2**